



**INSTRUCTIONS FOR: DRAX-104  
(03-09 KAWASAKI ZX-6R)**

**PERFORMANCE PRODUCTS**

- 1) Set the rear end of the motorcycle upright and straight (rear stand).
- 2) Remove the axle nut and pull the axle out.
- 3) Locate and identify the left and right Driven axle blocks.

**NOTE: Left part# DRAX-104L. Right part# DRAX-104R.**

- 4) Insert the axle into the Driven axle block, and then back through the wheel.

**NOTE: Thoroughly clean and re-grease axle before installation.**

- 5) Place the left Driven axle block into place and replace the original axle nut.

- 6) Check chain for proper tension and wheel alignment before tightening axle nut and installing split pin.

**NOTE: \*DUE TO THE IRREGULAR SHAPE OF THE ZX-6R SWING ARM, USE THE CENTER GROOVE LINE ON THE AXLE BLOCKS FOR PRIMARY ALIGNMENT. HASH MARKS ON THE AXLE BLOCKS ARE TO BE USED ONLY TO MEASURE THE AMOUNT EACH SIDE TRAVELS FORWARD OR BACKWARDS.\***

- 7) Apply blue Loctite to the 10mm supplied bolts and attach the sliders to the Driven axle blocks.

**NOTE: \*Consult your OEM owner's manual for proper torque values\***

Please contact us directly with any questions or concerns:

Tel: 1-866-5-DRIVEN

Email: [INFO@DRIVENRACING.COM](mailto:INFO@DRIVENRACING.COM)

**DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN**

*\*This product is sold for off road use only and is not intended for use on public roads. The purchaser of this product releases Driven Performance Products and their distributors of any liability pertaining to installation of purchased parts. Purchaser recognizes that any alteration or modification to the vehicle may increase the risk of injury or accident. For Off Road/Closed Course Use only.*